



(1)
Assembling the Top&Bottom
and frame with M5.5 * 10
self-tapping screw

(2)
Fixed the mounting profile
on the mounting angle with
four M5.5 * 10 self-tapping
screw, and measure the distance
between 2pcs transverse
mounting profile in 19"

(3)
Fixed the back panel on
the frame with M5.5 * 10
self-tapping screw

(4)
Insert the feet on the
bottom of side panel
into the small square
hole on the bottom frame,
make the quick opening
handle into the hole on the pole.

(5)
Put the door seat in the
bottom frame, then install
the front door on the cabinet

1.Top cover	1PC
2.M5.5*10 inner 6-angle self-tapping screw	26PCS
3.Frame	2PCS
4.Bottom	1PC

5.Mounting profile	4PCS
6.Back panel	1PC
7.Side door(panel)	2PCS
8.Front door	1PC